

### Aquavale 90° Bend & 120° Elbow Installation Instructions



TRUDESIGN™ 90°Bend and 120°Elbow are supplied with a Blue Port Seal. The Blue seal is thicker than the red seal that comes standard in the Aquavale base.

- Check that the standard Red Port seal is in place.
- Screw in the 90° or 120° tail and tighten with the Aquavale Spanner.
- If the final position / orientation of the tail is incorrect, carry out the following.
- Unscrew in the 90° or 120° tail then take out the Red Port Seal and then replace with the Blue Port Seal supplied.
- Screw back in the 90° or 120° tail and tighten with the Aquavale Spanner until the Tail is in the correct position.

NOTE: Do not use both the Red and Blue Port Seals together. Only one Port Seal is to be used at a time.