

[Menu](#)[Home](#) [Instructions](#)

Instructions

ACR EPIRB Models: RLB-27, RLB-28, RLB-32, RLB-33, RLB-35

1. Remove the 4 screws holding the 2 halves of the unit together
2. Separate top and bottom
3. Unplug batter connector from where it plugs in to the top half circuit board
4. Remove battery pack
5. Install new pack and plug connector back in
6. Clean all joining surfaces of dirt, sand, etc.
7. Apply silicone grease to the rubber seal
8. Join the top and bottom, being careful to avoid damaging the seal
9. Install the 4 screws
10. Perform a Self-Test on the unit