



SONY

[< Sony Support](#) | DSX-A415BT

Firmware Update "M 13 / S 35" for DSX-A410BT/A415BT

Adds a voice output setting function for hands-free

[Download](#)[Applicable Models](#)[About this download](#)[System Requirements](#)[File Info](#)[Preparation](#)[Download & Install](#)

Applicable Models

This information is for the following models:

- DSX-A410BT
- DSX-A415BT

IMPORTANT: This file is only for use with the models identified. Not all models are sold in all countries.

About this download

Benefits and improvements from the latest update

- Adds a voice output setting function for hands-free
- Improves the Bluetooth® connectivity

Previous Benefits and Improvements

- Resolves an issue where sound is distorted when HPF (High Pass Filter) is set to ON
- Resolves an issue where sound during a call is not output from a speaker of the main unit when the RINGTONE setting of the Bluetooth setup is set to 1

System Requirements

What You Need

- a computer with access to the Internet
- a USB storage device

Note:

- USB memory with exFAT format is not supported.
- USB memory with over 32GB capacity is not supported.

File Info

File Name

- DSX-A410BT_M13S35.zip

File Version

- M 13 / S 35

File Size

- 1.54 MB (1,618,710 byte)

Before You Start

- Applicable firmware versions:
 - If the firmware of your unit is version "M 13 / S 35" or above, you do not need to perform the update.

How to confirm the firmware version on the main unit

1. Turn the main unit "ON".
2. Press and hold the "SRC" button for 1 second on the main unit to turn the source off and display the clock.
3. Press the "MENU" button.
4. Turn the control dial to display "GENERAL", and press the control dial.
5. Turn the control dial to display "SET FIRMWARE", and press the control dial.
6. Turn the control dial to display "FW VERSION", and press the control dial. The current firmware version is then displayed.

Download & Install

1. Preparation: how to prepare a USB storage device for the firmware update

1. Connect the USB device to your PC and make sure you format it, selecting the FAT16 or FAT32 file system.
2. Make sure your PC is connected to the Internet.
3. Download the update file to your PC.
 - File name: DSX-A410BT_M13S35.zip
 - File size: 1.54 MB (1,618,710 byte)
4. Please unzip the downloaded zip file.
5. Copy the "DSX-A410BT_M13S35.U88" file and "DSX-A410BT_DSP_M13S35.up6" files to the root directory of the USB device connected to your PC
 - Note: The update will not be performed if the file is not copied to the root directory of the USB device or if the name of the file is modified.
6. Disconnect the USB device from your PC.

2. Update: how to update the firmware of the main unit using the USB storage device

Notes:

- This update procedure (in your car or boat) takes approximately 3 minutes to complete.
- Please make sure you follow all the steps indicated below.
- To prevent the battery voltage from becoming too low during the update process, it is recommended to perform this update with the car (or boat) engine running. Before starting the update process with the car (or boat) engine running, make sure the vehicle is parked in a safe place and keep the engine running until the update is complete.

1. Turn the main unit "ON".
2. Press and hold the "SRC" button for 1 second on the main unit to turn the source off and display the clock.
3. Press the "MENU" button.
4. Turn the control dial to display "GENERAL", and press the control dial.
5. Turn the control dial to display "SET FIRMWARE", and press the control dial.
6. Turn the control dial to display "FW UPDATE", and press the control dial.
7. Turn the control dial to display "FW UPDATE-YES", and press the control dial
8. When the message "INSERT USB" is displayed, connect the USB storage device to the USB port on the front panel of the main unit.
9. The update takes approximately 3 minutes to finish, and after it finishes successfully, the unit automatically restarts.
10. Confirm that the firmware version is updated to version M 13 / S 35.



Product Repair

Repair information and service assistance